NON-RETURN VALVE / ANTI-FLOODING SYSTEM

REDI

Standards

Valve range from Ø100 to Ø200 is fully complying to $\pmb{\mathsf{EN}}\,\pmb{\mathsf{13564}}$



NORMAL WORKING SITUATION



EFFECTIVE ANTI-FLOODING



Ø 160 (solvent cement)







Ø 250 (solvent cement)

Ø 315 (rubbber ring) Ø 400 (rubbber ring)

Ø 160 (solvent cemen

INSTALLATION DETAILS

Every valve is delivered in single carton box including installation instructions



INSTALLATION

Ensure the valve is set horizontally, as it already has a built-in fall. Beware of the direction of flow as indicated by the arrow on the cover of the valve.



OPERATION

The Redi anti-flooding device for use in horizontal pipes closes the pipeline automatically when backflow occurs. Ensure the handle is on the "OPEN".



EMERGENCY CLOSURE DEVICE


The option exists to lock the valve in the "CLOSED" position for added security (no through drainage allowed).



MAINTENANCE

The emergency closure device should ideally be tested one every six months. In case of dirt and deposits, remove the cover, clean parts, check gaskets and replace any damaged parts. We strongly recommend a complete servicing at least once every twelve months.











EMERALD VINYL CORPORATION

Plant: 24 Oliveros Drive, Balintawak, Quezon City, Philippines Tel. nos.: 8361-6101 Fax no.: 8361-6740

sales@emeraldvinvl.com